



**CUTTER & LOCK STUD** 

PRIMER POCKET CLEANER

**CHAMFER TOOL** 

WWW.LEEPRECISION.COM

LEE PRECISION, INC HARTFORD, WISCONSIN 53027

## Purchase the appropriate case length gauge for the cartridge you are reloading to complete this kit

## CUTTER & LOCK STUD INSTRUCTIONS



Lock deprimed case in shell holder with the lock stud. Insert pilot into case with pin in flash hole and rotate until it stops cutting. If no metal is removed, case does not need trimming.

Hex shank can be installed in drill to spin case. Case can be chamfered inside and outside with a Lee chamfer tool, and you can also polish the case with Scotch Brite or No. O steel wool.

## PRIMER POCKET CLEANER INSTRUCTIONS

Insert appropriate end of primer pocket cleaner into flash hole. Rotate the primer pocket cleaner to remove residue from the pocket.

## CHAMFER TOOL INSTRUCTIONS

Insert pointed end of tool into case neck. Turn tool to chamfer. Insert case neck into open end of tool. Turn to chamfer the O.D.



WARNING: Steel parts in this product may be alloyed with trace amounts of lead and other elements which are known to the State of California to cause reproductive harm and cancer. For more information, go to www.P65Warnings.ca.gov. To prevent exposure, do not alter the product by welding, grinding, etc.